



TECHNOLOGY OF MATERIALS

4020 N. Palm Street, # 202
Fullerton, CA 92835

Sam Iyengar Ph.D.
Technical Director

Mr. William Puckett
UFOS Northwest
11505 Eastridge Dr. NE Apt. 306
Redmond, WA 98053

April 17, 2013

Dear Bill

Enclosed please find a report on the analysis of the unknown object.
Please call me if you have any questions or concerns.

Sincerely,

Sam Iyengar

Phone: (714) 446-9227

www.xraydiffrac.com

Fax: ((714) 446-9229

SEM/EDS Analysis of an Unknown Object

Introduction:

An unknown metal sample was received at the laboratory for analysis. It was requested that the chemistry of the object be determined. The object was analyzed by SEM/Energy Dispersive X-ray Analysis to determine the chemical constituents. The following report summarizes the analytical results.

Materials and Method:

The sample labeled as follows was analyzed.

1) Unknown Metal

Scanning Electron Microscopy /Energy Dispersive X-ray Analysis (SEM/EDS)

In this technique, an electron microscope with an energy dispersive X-ray spectrometer is used for analysis. The electron beam in the microscope causes specimens to emit x-rays including those from the k, l and m atomic shells. Spectrometer counts of these x-rays, which are said to be “characteristic” of the elements present in the specimen, can be used to calculate composition for a full qualitative analysis. The analysis is non-destructive and is accurate to ~ 1 %.

This technique determines the elements (like Si, O, Ca, Fe, etc) present in the powder sample

Results and Discussion:

EDXRF data is also included. Elemental composition of the main body is shown in the following Table 1

- The metal is mostly iron (Fe) w/ some manganese (Mn). It also has some silicon (Si) and calcium (Ca) along with aluminum (Al). These elements may be from soil contamination.

Table 1: Elemental Composition

Elements (wt. %)	Metal Piece
Sodium	0.2
Magnesium	0.5
Aluminum	1.4
Silicon	6.1
Sulfur	0.2
Chlorine	0.3
Calcium	2.0
Potassium	0.4
Iron	86.0
Manganese	2.5



